













Operating Instructions

Making Calls






Press the  button or lift the handset first.

Feature	Operation
Inter Office Calling Station to station dialing within the system.	extension number or 
Individual Line Access Any CO line can be directly selected.	 → phone number
Automatic Line Access An idle CO line will be automatically selected.	 → phone number
System Speed Dialing Any extension users can make an outside call with a simple operation.	 → access code
One-Touch Dialing A system feature or a telephone number can be activated with simply pressing the Programmable Feature button programmed in advance.	Dialing: 
	Programming: Set the memory switch to "PROGRAM".  → one-touch code → phone number →  Replace the memory switch to the "SET".








When a Line is Busy

Automatic Call Back Busy (Camp-on) This feature automatically notifies you when the busy CO line or extension becomes free.	Outside Calls:  → Hear a busy tone →  → Hang up
	Intercom Calls: extension number → Hear a busy tone →  → Hang up
Redial The last dialed number will be redialed at one touch. • Automatic redial can work in upgraded systems.	 or Lift the handset → 

Receiving Calls

Feature		Operation
Answer	Answering the incoming calls.	 or 
Automatic Answer—Intercom	The extension user can answer an intercom call in the automatic hands-free mode.	Setting:  The indicator lights in red.
		Canceling:  The indicator goes out.
Dial Call Pickup	An extension user can answer any ringing extension within their own extension group.	 <ul style="list-style-type: none"> •The pickup code depends on the EMSS Control Unit.

While Having a Conversation

Hold—CO Line	An outside call will be put on hold during a conversation.	 The CO line indicator flashes in green. Other extensions flash in red.
		Retrieving:  The indicator lights in green.
		Retrieving from another extension:  The indicator lights in green.
Hold—Intercom	An intercom call will be put on hold during a conversation.	 The intercom indicator flashes in green.
		Retrieving:  The indicator lights in green.
Call Transfer to Extension	An outside call or an intercom call will be transferred to any extension.	Transferring after the other extension answers:  → extension number → Wait for an answer and announce → Hang up
		Transferring without announcing to the other extension:  → extension number → Hang up

For further details, please refer to the Electronic Modular Switching System (EMSS) Control Unit Manual.

System Features	Operation

Please use this Operating Instructions for basic operations, and for other features, please refer to the Electronic Modular Switching System (EMSS) Control Unit Manual.

Notice

A series of the beep tone may sound periodically when the MEMORY switch is set to the "PROGRAM". This is a normal condition.

Matsushita Electric Industrial Co., Ltd.

Central P.O. Box 288, Osaka 530-91, Japan